

# Main Slalom Screen

---



Highlight menu arrow and press **up** to change modes

Full segment time

Tachometer

# Practise Mode / Timing Mode/ WT Previous Times

---



Highlight slalom and press **up** key



Use **up** key to toggle between modes/timing option

# All Ball Timing - Slalom

---




Press **down** key for “all ball times”



# Jump Mode - New Three Segment Timing

---

Press **down** key for “all ball times”




R&L Class Tournaments must use the new I.W.S.F. timing rule. You must select “ONE MAGNET” method to see these times.

After a brief moment, the traditional two segment times will appear 5.47/2.73

# Slalom - One Magnet Timing

---



When running with one “Smart Timer” magnet sensor on passenger side, only two magnets are required as shown.